

6210 Mighty Mite Assembly Instructions

INSTRUCTIONS OF USE:

1. Place end caps on all ends before assembly.
2. Align grid section with top and bottom center holes (A) on end arches and insert bolts. Fasten with lock washer and nut. DO NOT TIGHTEN.
3. Align brace poles with holes (B) on end arches, insert bolts. Fasten with lock washer and nut.
4. Tighten all nuts firmly.

