

GROUND CONTROL SYSTEMS®
VR-2 Wall Mounted
LAK4 Mounting Instructions

TOOLS NEEDED FOR INSTALLATION

1. Gloves and safety glasses
2. 3/8" Hex Socket Drill bit and Drill
3. Tape Measure and Pencil
4. Level

NOTE: These instructions are for installation of the wall mounted Offset Vertical Bike Rack into a wood backed wall only.


1. Remove the contents from the box and make sure all the components are there.

In the Box:

1. Offset Vertical Bike Rack (2-bike shown)

Additional Materials


- (4) 1/4" x 3" Lag Screws




WARNING:

Backing must be adequate to support the full load of the rack and bicycles. 3/4" or greater is recommended. However building code and application may vary.

2. Using a tape measure and pencil, layout and mark the placement of the racks. Be sure to consider ADA requirements and local ordinances when placing racks.



3. Using a drill with a 3/8" socket bit, mount the rack in the marked out location using the upper right mounting hole first. Proceed to securing the rack using the other three mounting holes while ensuring it remains straight by use of a level.



GROUND CONTROL
SYSTEMS®
Innovative Bike & Board Parking

info@groundcontrolsystems.com | 800-630-7225
www.groundcontrolsystems.com