


**GROUND CONTROL SYSTEMS®**  
**Offset® Ledgerboard**  
**Mounting Instructions**

NOTE: These instructions are for the ledgerboard method which must be used on wood studded walls only.

METAL STUDDED WALLS MUST USE A TOGGLE NUT (see step 1) AND UNISTRUT RAILS OR SIMILAR


1. Secure 2x4 and 1x4 ledgerboards to wall, using 1/4" x 4" flat head screws, into wood studs\*  
 \*use metal struts and toggle nuts for metal studded walls (see separate instructions)
2. Secure racks to ledgerboards using 1/4" x 1.5" lag screws\*\*  
 \*\*ledgerboard material and ledgerboard hardware not included in estimate

LEDGERBOARD MOUNT  
 2"x4" WOOD BOARD



DETAIL A

KICKBOARDS  
 1"x4" WOOD BOARD



DETAIL B

